

INSTALLATION INSTRUCTION

Fabric Wall Sconce

E-WS-132523

East Grove

• H O M E •

CAUTION: To prevent electrical shock, ensure electricity has been turned off at the circuit breaker before beginning.

- Read all instructions before installing.
- System is intended for installation by a licensed electrician in accordance with the National Electrical Code (NEC) and local regulations.
- When handling the fixture, do not apply pressure to the LEDs. Hold the fixture by the base only.
- Retain installation instructions for future maintenance reference.

WARNING: All parts must be used as indicated in these instructions. This product is designed for use only with the supplied parts and/or accessories designated for use by **EastGroveHome**. Substitution of parts or accessories not designated for use with this product by **EastGroveHome** could result in personal injury or property damage, and will void the warranty. Contact an authorized dealer or the manufacturer if any parts are damaged or missing.

MAINTENANCE NOTE: Coastal conditions may cause mineral and residue build-up on the fixture. We recommend that customers in coastal areas clean all external surfaces of the fixture once every two weeks with a wet cloth.

MISE EN GARDE: Pour éviter tout choc électrique, assurez-vous que le disjoncteur soit mis hors tension avant de commencer.

- Lisez toutes les instructions avant l'installation.
- Le système doit être installé par un électricien licencié conformément au code national de l'électricité (NEC), et également aux règlements locaux.
- Lors de la manipulation du luminaire, n'appuyez pas sur les LED. Tenez-le uniquement par la base.

ATTENTION: Toutes les pièces doivent être utilisées comme indiqué dans ces instructions. Ce produit est conçu pour être utilisé seulement avec les pièces et/ou accessoires fournis pour être utilisés avec les produits **EastGroveHome**. Remplacer des pièces ou accessoires non conçus pour ce produit **EastGroveHome** pourrait causer des dommages corporels ou matériels et pourrait également causer l'annulation de la garantie. Veuillez contacter un revendeur autorisé ou le fabricant si des pièces manquent ou sont endommagées.

NOTE D'ENTRETIEN: Les conditions côtières peut causer une accumulation de minéraux et de résidus sur le luminaire. Nous recommandons aux clients qui résident dans les zones côtières de nettoyer toutes les surfaces externes du luminaire une fois toutes les deux semaines avec un chiffon humide.

HARDWARE

A



Junction Box Screws
Qty: 2pcs

B



Mounting Screw
Qty: 1 Extra

INSTALLATION INSTRUCTION

Fabric Wall Sconce

E-WS-132523

East Grove

• H O M E •

Fig.1





Fig.2



PREPARATION

1. Shut off the power at the circuit breaker and remove existing fixture, including the crossbar.
2. Carefully unpack your new fixture and lay out all the parts on a clear area. Be careful not to lose any small parts necessary for installation.

MOUNTING THE FIXTURE

3. Secure the mounting back plate to the junction box using standard junction box screws that comes with the junction box.
Note: Using any other non-original manufacturer provided junction box screw may result in safety issue.
4. Tighten the rod to the fixture.
5. Secure the fabric shade to the lampholder using the socket ring.
6. Tightly screw the E26 base onto the lampholder, then magnetically attach the rechargeable lamp to the E26 base.

COMPLETING THE INSTALLATION

4. Mount the fixture against the mounting back plate and secure using the mounting screw.

CONTROL METHODS:

(1) Button control:

- a. Single - click to switch modes: Switch colors, 15 colors in total.
- b. Long press the switch: Press and hold for five seconds to turn off the power.

(2) Remote control functions:

1. Power on/off button (ON/OFF)
2. Color temperature cycle switching: Warm white / Mixed white / Cool white
3. Brightness adjustment: There are 10 levels of increase or decrease in total.
4. Timing function: Automatically turn off in 30 minutes / 60 minutes / 120 minutes (canceled by any key).
5. Lighting mode: a. Smooth lighting mode : Smoothly change the color of the light.
b. Flash lighting mode : Flashing change the color of the light.